




Parts Manual

LP5500 389cc (Model 0060010)

NOTICE!

The information in this manual is known to be accurate as of the date of release shown on the cover. However, engineering changes can occur without notice. To obtain the proper parts, please be sure to use the serial number of the unit being serviced when ordering from this manual. Always refer to any parts notes and changes before ordering. All other parts not shown in this manual can be found on Generac's exploded view drawings online on GENservice at www.generac.com.



LP5500



Item	Part #	Qty	Description
1	OJ8191AST19	1	CONTROL SIDE PANEL - DARK GRAY
2	OG8382	8	SCREW PPPH #8-16 X .66" BZC
3	OH1780	10	CURVED HEAD M8-1.25 X 41MM LNG
4	OJ9357A	1	ASSEMBLY CONTROL PANEL LP5500
5	OK0417	1	CIRCUIT BREAKER, ON/OFF SWITCH
6	OG9391	1	COVER, OUTLET
7	OG9392	2	COVER, OUTLET
8	OJ9358	1	PLATE, CNTL PNL FACE
9	OG8321	1	METER, HOUR
10	OG8758	1	OUTLET 30A 120/250V SPCGR
11	OD4968	2	OUTLET 20A 120V DPLX 6342BK
12	OJ9355A	1	CONTROL PANEL ENCLOSURE
13	OJ93540ST03	2	BRACKET, FOOT
14	OK0098	4	NUT, M8
15	OK0099	2	FOOT, RUBBER
16	OK0105	2	NUT, M6
17	OK0100	2	BOLT, FLANGE M6X28
18	OJ9808	2	PIN, AXLE
19	OH9589A	2	WHEEL 10"D X 3" NVR FLT IND GR
20	OB1214	6	BOLT, M8X45
21	OK0485	2	PIN, LOCKING
22	OJ9385	1	STRAP ASSY, TANK
23	OJ79090110	2	WASHER, NYLON
24	OJ80700ES03	1	BRACKET, TANK SUPPORT
25	OJ35220156	1	BOLT, M6X20
26	OK0093	1	WASHER, SPECIAL LOCK
27	OG84420272	1	NUT, M6
28	OJ47870118	1	WASHER, FLAT 6X0.8
29	OK0094	1	NUT, M6
30	OK0092	1	WIRE ASSY., GRND
31	067989	4	NUT, M8
32	049808	2	WASHER, FLAT
33	OH3443	3	PIN, COTTER
34	OK09150110	4	VIB MOUNT, ENGINE
35	OG84420107	4	NUT, M10
36	OH1782	10	NUT, LOCKING CAP M8
37	OK0393	1	BUMPER TANK STOP - RUBBER
38	OJ80630ES03	1	CRADLE WELDMENT LP5500
39	OH9760	4	CAP END NYLON BLACK
40	OJ5347	1	BUTTON, SNAP (DETENT)
41	OJ80720ES03	1	FRAME HANDLE
42	OJ8363	1	ASSY ALTERNATOR 5500W BT AL/AL
43	OH0919	1	BRUSH, ALTERNATOR
44	OJ83630111	1	TERMINAL

Item	Part #	Qty	Description
45	070264	1	WASHER, FLAT M10X4
46	OH91980171	1	HOUSING, REAR BEARING
47	OJ83630110	2	BOLT, M5X204
48	OH2579B	1	AVR 5.5-7.5KW VISION ALT
49	OH3049	1	COVER ALTERNATOR INLET 5-7KW
50	OJ4967	6	BOLT, M5X12
51	OJ4968	3	BOLT, M5X16
52	OJ8448	1	BOLT, ROTOR M10X255
53	OJ9069	4	BOLT, M6X170
54	OG8542	1	BRACKET, MUFFLER
55	0E9470	4	BOLT, M8X16
56	OJ79090113	1	MUFFLER
57	OJ4691	1	GASKET EXHAUST 389
58	0E9507B	2	BOLT, M8X25
59	OJ81920ST19	1	EXHAUST SIDE PANEL - DARK GRAY
60	OJ9352	1	COVER, KNOB SCREW
61	OJ79090111	1	SCREW, SELECTOR KNOB M5x10
62	OJ8358	1	KNOB, SELECTOR
63	OJ79090112	4	SCREW, M6X50
64	OJ81940ST15	1	COVER, TOP(BACK)
65	0F9504	1	GROMMET 5/8" X 1 1/8" X 5/16"
66	OG8442F122	1	HOSE, FUEL TANK TO REGULATOR
67	OJ8195	1	ASSY SINGLE POINT CTRL SYSTEM
68	OJ79090114	1	BUMPER, RUBBER
69	OG84420272	4	NUT, M6
70	OJ8203	1	BRACKET, SINGLE POINT CNTRL
71	OG8442F124	1	REGULATOR, 180 DEGREE GHG PRSHR
72	OH7606	8	SCREW, M6X16
73	OJ97360ST15	1	TOP COVER FRONT ACCESS - ORA
74	OJ6057	1	HOSE, VENT
75	OJ6058	1	HOSE, FUEL
76	048031J	2	CLAMP, FUEL HOSE
77	OG8442F	1	ENGINE 389 PS W/ REGULATOR
78	OJ00620100	1	BOLT, M5X10
79	OH9761	1	ALTERNATOR SCROLL
80	OJ86620104	1	BAFFLE
81	OG8442C112	1	BRACKET, AIR CLEANER
82	OG84420194	1	BOLT, M6X12
83	OJ35220161	2	NUT, M8
84	OG8442F111	1	MANIFOLD, EXHAUST
85	OG9028	1	GASKET, EXH CYLNRD
86	OJ5207C110	1	ARRESTOR, SPARK
87	OH0265C	2	CB 20A 1P CUL/CSA

©2013 Generac Power Systems, Inc. All rights reserved.
Specifications are subject to change without notice
No reproduction allowed in any form without prior written consent from Generac Power Systems, Inc.