

# MINI BUTANE FLAME THROWER

Stock Number W2002

## OWNERS MANUAL

1. Flame guard or nozzle
2. Air flow control valve
3. Ignition button
4. Torch safety lock
5. Gas filler valve



### SAFETY INFORMATION

1. Always keep the tool out of the reach of children.
2. Never leave the tool unattended when in use.
3. Read and understand the directions completely.
4. Use only approved butane lighter fluid as fuel.
5. Keep clear of the torch flame. The flame is difficult to see, so work with caution.
6. The flame nozzle becomes very hot. Do not let it touch your or any combustible material during and after use, until it has cooled.
7. To avoid overheating the torch, allow short rest periods between each minute (approx.) of uninterrupted use.
8. If ambient temperature is too cold or insufficient oxygen is available, the flame will not ignite.
9. Continuously holding the torch downwards may extinguish the flame.
10. Never store your torch in direct sunlight. Any area where a stove or heater generates high temperatures should be avoided. Less than 104°F (40°C)
11. Disassembly, modification or miss use of the Mini Flame Thrower may be hazardous.

### ▲ WARNING

*It is the owner and/or operators' responsibility to study all WARNINGS, operating, and maintenance instructions contained on the product label and instruction manual prior to operating this tool. The owner/operator shall retain product instructions for future reference.*

*The owner and/or operator are responsible for maintenance, maintaining all decals or warning labels and while in use, maintaining the unit in good working order. If the owner and/or operator are not fluent in English, the product warnings and instructions shall be read and discussed with the operators' native language by the purchaser/owner or his designee. Make sure that the operator comprehends its contents. Safety information shall be emphasized and understood prior to usage.*

*Protect yourself and others by observing all safety information.*

*Failure to comply with instructions could result in personal injury and/or property damage!  
If you encounter any problems or difficulties, please contact our customer service department at: 1-800-426-1262 between 6:30 a.m. and 4:30 p.m. Pacific time.*

**PT**  
**Performance Tool**

Please read these instructions carefully and retain them for future use.

Performance Tool®

## INSTRUCTIONS FOR USE

1. Read and understand these instructions and cautions.
2. To fill your Mini Flame Thrower with butane lighter fluid turn the torch over to access the bottom.
3. Look for the gas injection valve (5) in the center. Attach your Butane fuel cell's nozzle to the filler valve on your torch. Fill the holding tank.
4. The fold over knob with the – symbol and the + symbol turns to open the valve. Use this valve to adjust the volume of butane supplied to the torch, fine tuning the flame.
5. To ignite the torch slide the air control valve (2) to the middle. The air flow can be adjusted from a normal flame to a pinpoint flame by moving the valve right to left.
6. Slide the Off/Lock button (4) from the lock position to the off position.
7. Use your thumb to press the ignition button (3) hold it down to keep the torch lit. It may be necessary to repeat this once or twice to light the torch.
8. To extinguish the torch, release the ignition button (3). Residual gas may keep the flame burning briefly, so make sure the flame is extinguished before setting the torch aside.
9. After the fuel in the torch has been consumed, and has completely cooled, simply refer to steps 2. and 3. to refill. The run time on a full tank is approximately 20 minutes of use.

### 1 YEAR LIMITED WARRANTY

PERFORMANCE TOOL® extends only the following warranties, and only to original retail purchasers. These warranties give specific legal rights. Except where prohibited by local law, the law of the State of Washington governs all warranties and all exclusions and limitations of warranties and remedies. There may be other rights which vary from state to state.

PERFORMANCE TOOL® warrants the product to be free from defects in materials and workmanship under normal use and service. A defective product may be returned for a free replacement within 90 days from the date of purchase, provided that product is returned to place of purchase immediately after discovery of defect. After 90 days and up to one year from date of purchase, PERFORMANCE TOOL® will replace at no charge any parts which our examination shall disclose to be defective and under warranty. These warranties shall be valid only when a sales receipt showing the date of purchase accompanies the defective product or defective part (s) being returned. For part (s) after 90 days, please remit your request, postage prepaid to:

PERFORMANCE TOOL, P.O. Box 88259 Tukwila, WA 98138

These warranties exclude blades, bits, punches, dies, bulbs, fuses, hoses, and other consumables which must be replaced under normal use and service. These warranties shall not apply to any product or part which is used for a purpose for which it is not designed, or which has been repaired or altered in any way so as to affect adversely its performance or reliability, nor shall these warranties apply to any product or part which has been subject to misuse, neglect, accident or wear and tear incident to normal use and service.

PERFORMANCE TOOL® does not authorize any other person to make any warranty or to assume any liability in connection with its products.

Except for warranties of title and the limited express warranties set forth above, PERFORMANCE TOOL® makes no express or implied warranties of any kind with respect to its products. In particular, PERFORMANCE TOOL® makes no implied warranty of merchantability and no implied warranty of fitness for any particular purpose, except that for goods purchased primarily for personal, family or household use and not for commercial or business use, PERFORMANCE TOOL® makes an implied warranty of merchantability (and, if otherwise applicable, an implied warranty of fitness for a particular purpose), but only for the particular qualities or characteristics, and for the duration, expressly warranted above.

The laws on limitation of implied warranties may differ from state to state, so the above limitations may not apply in all cases.

PERFORMANCE TOOL® shall not be liable for consequential, incidental or special damages resulting from or in any manner related to any product, or to the design, use, or any inability to use the product. The sole and exclusive remedy for a defective product or part shall be the repair, or replacement thereof as provided above. The laws on limitation of remedies or on consequential, incidental or special damages may vary from state to state, so the above limitations may not apply in all cases.

© Copyright 2015 WILMAR CORPORATION, P.O. Box 88259 Tukwila, WA 98138

On occasion, after printing of our literature is completed, our manufacturers may make changes and/or modifications to merchandise which will not be reflected in this manual. Although we strive to maintain complete and accurate information, it is possible in some instances, that the product may differ slightly from printed specifications. Illustrations are intended for reference only. Actual merchandise may vary. Wilmar is not responsible for typographical errors.